Dokumentation der Abschlussprüfung im Ausbildungsberuf "Mathematisch-Technische*r Softwareentwickler*in", Prüfungsbereich: "Entwicklung eines Softwaresystems"

Entwicklung einer Software zur Simulation einer "Spidercam"

Patrick Gustav Blaneck (20000)

IT Center RWTH Aachen University

Programmiersprache: **?** Python







Eidesstattliche Erklärung

Ich erkläre verbindlich, dass das vorliegende Prüfprodukt von mir selbstständig erstellt wurde. Die als Arbeitshilfe genutzten Unterlagen sind in der Arbeit vollständig aufgeführt. Ich versichere, dass der vorgelegte Ausdruck mit dem Inhalt der von mir erstellten digitalen Version identisch ist. Weder ganz noch in Teilen wurde die Arbeit bereits als Prüfungsleitung vorgelegt. Mir ist bewusst, dass jedes Zuwiederhandeln als Täuschungsversuch zu gelten hat, der die Anerkennung des Prüfprodukts als Prüfungsleistung ausschließt.

Name: Patrick Gustav Blaneck Aachen, den 1. Dezember 2022

Unterschrift der/des Auszubildenden

Inhaltsverzeichnis


1 Aufgabenanalyse


Im Rahmen dieses Softwareprojekts soll ein Programm erstellt werden, welches aus gegebenen Eckdaten und einer Liste an Instruktionen die Bewegung einer sogenannten *Spidercam* simuliert. Definition aus der Aufgabenstellung:

Spidercams sind Kameras, die von vier Drahtseilen in der Luft gehalten werden. Die Drahtseile sind an vier festen Positionen verankert, können aber über dort angebrachte Seilwinden in der Länge variiert werden.

Die besondere Schwierigkeit besteht unter anderem daraus, dass:

- eine lineare Bewegung der Spidercam nicht unbedingt in einer linearen Veränderung der Seillängen resultiert (siehe Abbildung ??),
- Instruktionen "live" verarbeitet werden also nicht nur die Bewegung der Spidercam, sondern auch die Veränderung der Seillängen in "Echtzeit" simuliert werden muss¹,
- die Spidercam sowohl beschleunigen als auch abbremsen muss und
- Instruktionen abgebrochen und in eine Warteschlange gestellt werden können.





(a) Lineare Bewegung der Spidercam

(b) Veränderung der Seillängen

Abbildung 1: Beispiel für die Veränderung der Seillängen bei einer einfachen linearen Bewegung der Spidercam. Es ist zu erkennen, dass sich die Seillängen nicht linear verändern. Die Farbe der Bewegungspunkte gibt dabei an, wie schnell sich die Spidercam in diesem Moment bewegt.

Die einzelnen Punkte werden in den folgenden Abschnitten genauer erläutert.

¹Die Aufgabenstellung spricht konkret davon, dass die Instruktionen nicht vorausschauend verarbeitet werden dürfen.

1.1 Eingabe

Format

Die Parameter für die Simulation einer Spidercam werden in Form einer Textdatei eingelesen. Ein Beispiel für eine Eingabedatei ist in Abbildung ?? zu sehen.

```
# Beispiel
dim 70 100 30
start 10 80 10

vmax 6
smax 2
freq 2
0 50 40 30 # Instruktion 1
20 10 80 10 # Instruktion 2
22 50 40 30 # Instruktion 3
10 23 35 50 30 # Instruktion 4
11 27.5 10 80 20 # Instruktion 5
```

Abbildung 2: Beispiel für eine Eingabedatei

Kommentare werden mit einem # eingeleitet und dauern bis zum Ende der Zeile an. Die Parameter werden in der Reihenfolge der folgenden Liste eingelesen²:

- Dimension des Spielfelds (dim x y z),
- Startkoordinaten der Spidercam (start x y z),
- Maximalgeschwindigkeit der Spidercam (vmax v),
- (Maximal-)Beschleunigung der Spidercam (amax a),
- Diskretisierung der Bewegung (freq f),
- Beliebige Anzahl an Instruktionen mit Zeitpunkt und Zielkoodinaten (t x y z).

Fehlerquellen und -behebung

Die offensichtlichste Fehlerquellen sind:

- Dimension besitzt nicht positive Werte
- Startposition außerhalb des Spielfelds
- Maximalgeschwindigkeit oder -beschleunigung sind nicht positiv
- Diskretisierung ist nicht positiv
- Instruktionen außerhalb des Spielfelds³

Fehlerhafte Eingaben werden vor Initialisierung der Simulation abgefangen und mit einer Fehlermeldung beendet.

²Von einer *syntaktisch* korrekten Eingabedatei kann ausgegangen werden.

³Von chronologisch korrekt sortierten Instruktionen kann ausgegangen werden.

1.2 Ausgabe

Format

Für die Simulation sollen zwei CSV-Ausgabedateien erzeugt werden, die zu diskreten Zeitpunkten von t=0 bis zum Zeitpunkt der Beendigung der letzten Instruktion t_c die Längen der Drahtseile und die Positionen der Spidercam in der in der Eingabedatei angegebenen Frequenz f [Hz = s^{-1}] speichern.

Ausgabedatei 1 (siehe Abbildung ??) enthält pro Zeile die Längen eines Seils zu jedem diskreten Zeitpunkt $t_i = i \cdot f^{-1}$, wobei $i \in [0, t_c \cdot f]$. Für jeden Verankerungspunkt wird also eine Zeile angelegt.

Ausgabedatei 2 (siehe Abbildung ??) enthält zeilenweise:

- Dimension des Spielfelds,
- diskrete Zeitpunkte,
- x-Koordinate der Spidercam zu jedem Zeitpunkt t_i ,
- y-Koordinate der Spidercam zu jedem Zeitpunkt t_i ,
- z-Koordinate der Spidercam zu jedem Zeitpunkt t_i .

```
83.0662,82.90594,82.427746,[...],64.0056,64.03124

101.9803,101.7352,101.0,[...],44.94510,44.7213

30.0,30.111,30.4576,[...],77.86780,78.1024

66.332,66.20721,65.8356,[...],63.14055,63.2455
```

Abbildung 3: Beispiel für eine Ausgabedatei 1

Abbildung 4: Beispiel für eine Ausgabedatei 2

1.3 Mathematische Modellierung

Berechnung der Seillängen

Die Verankerungspunkte der Drahtseile sind eindeutig durch die Dimension des Spielfeldes gegeben. Es gilt:

$$R_1 = \begin{pmatrix} 0 \\ 0 \\ d_z \end{pmatrix}, \quad R_2 = \begin{pmatrix} d_x \\ 0 \\ d_z \end{pmatrix}, \quad R_3 = \begin{pmatrix} 0 \\ d_y \\ d_z \end{pmatrix}, \quad R_4 = \begin{pmatrix} d_x \\ d_y \\ d_z \end{pmatrix}$$

Die Längen der Drahtseile l_i zu einem beliebigen Punkt im Raum A = (x, y, z) sind dann trivialerweise gegeben durch:

$$l_i = d(R_i, A) = ||(R_i - A)||_2 = \sqrt{(x - R_{i,x})^2 + (y - R_{i,y})^2 + (z - R_{i,z})^2}$$

Bewegung der Spidercam

Die Konstanten der Eingabedatei $a_{\rm max}$ und $v_{\rm max}$ werden hier als gegeben betrachtet. Mithilfe dieser Konstanten können dann der Zeitraum $t_{\rm max}$ und die Distanz $d_{\rm max}$ berechnet werden, die die Spidercam in der Simulation benötigt, um die maximale Geschwindigkeit $v_{\rm max}$ zu erreichen. Es gilt:

$$t_{\text{max}} = \frac{v_{\text{max}}}{a_{\text{max}}}$$
 und $d_{\text{max}} = \frac{v_{\text{max}}^2}{2 \cdot a_{\text{max}}}$

Die maximale Geschwindigkeit v_{max} wird also nach t_{max} bzw. d_{max} erreicht.

Eine Bewegung der Spidercam ist dann eindeutig durch den Startpunkt *A* und den Zielort *B* gegeben. Es können zwei Fälle unterschieden werden.

Eine *dreiphasige Bewegung* tritt auf, wenn die Spidercam die maximale Geschwindigkeit v_{max} auf dem Weg von A nach B erreichen kann.

Es gilt($d(A, B) > 2 \cdot d_{max}$)

$$\underbrace{\frac{(A)}{\mathrm{Start}}} \to \underbrace{\left(A + \frac{d_{\max}}{d(A,B)} \cdot (B-A)\right)}_{\mathrm{Zwischenpunkt}} \to \underbrace{\left(B - \frac{d_{\max}}{d(A,B)} \cdot (B-A)\right)}_{\mathrm{Zwischenpunkt}} \to \underbrace{\frac{(B)}{d(A,B)} \cdot (B-A)}_{\mathrm{Zwischenpunkt}} \to \underbrace{\frac{(B)}{d(A,B)} \cdot (B-A)}_{\mathrm$$




Abbildung 5: Bewegung der Spidercam in drei Phasen. t_a entspricht dem Zeitraum, in dem die Spidercam maximal beschleunigt wird. t_b ist der Zeitpunkt, an dem abgebremst wird und t_c ist der Zeitpunkt, an dem die Spidercam ihren Zielort erreicht hat.

Es gilt also, dass nach t_{max} bzw. d_{max} der Zwischenpunkt t_a erreicht wird, an dem die maximale Geschwindigkeit v_{max} erreicht ist. Danach bewegt sich die Spidercam mit konstanter Geschwindigkeit v_{max} bis zum Zeitpunkt t_b , ab dem abgebremst werden muss, um am Zielort die Geschwindigkeit 0 zu erreichen. Analog zum Beschleunigen

benötigt die Spidercam zum Abbremsen auf 0 die Zeit t_{\max} bzw. die Distanz d_{\max} . Für die Phase der konstanten Geschwindigkeit gilt also:

$$d_{\text{CON}} = d(A, B) - 2 \cdot d_{\text{max}}$$

Da die Geschwindigkeit konstant ist, gilt für die Zeit t_{CON} und damit t_b :

$$t_{\text{CON}} = \frac{d_{\text{CON}}}{v_{\text{max}}} = \frac{d(A, B) - 2 \cdot d_{\text{max}}}{v_{\text{max}}} \implies t_b = t_{\text{max}} + t_{\text{CON}}$$

Für diese Phase gilt damit (siehe auch Abbildung ??):

$$a(t) = \begin{cases} a_{\text{max}} & \text{für } 0 \le t \le t_a \\ 0 & \text{für } t_a < t \le t_b \\ -a_{\text{max}} & \text{für } t_b < t \le t_c \end{cases}$$

$$v(t) = \int_0^t a(u) \, \mathrm{d}u = \begin{cases} a_{\max} \cdot t & \text{für } 0 \le t \le t_a \\ v_{\max} & \text{für } t_a < t \le t_b \\ v_{\max} - a_{\max} \cdot (t - t_b) & \text{für } t_b < t \le t_c \end{cases}$$

$$s(t) = \int_0^t v(u) \, du = \begin{cases} \frac{a_{\max}}{2} \cdot t^2 & \text{für } 0 \le t \le t_a \\ s(t_a) + v_{\max} \cdot (t - t_a) & \text{für } t_a < t \le t_b \\ s(t_a) + s(t_b) + v_{\max} \cdot (t - t_b) - \frac{a_{\max}}{2} \cdot (t - t_b)^2 & \text{für } t_b < t \le t_c \end{cases}$$

Eine *zweiphasige Bewegung* (siehe Abbildung ??) tritt auf, wenn die Spidercam die maximale Geschwindigkeit v_{max} nicht auf dem Weg von A nach B erreichen kann.

Es gilt $(d(A, B) \le 2 \cdot d_{\text{max}})$:

$$\underbrace{(A)}_{\text{Start}} \to \underbrace{\left(A + \frac{d(A,B)}{2} \cdot (B-A)\right)}_{\text{Zwischenpunkt}} \to \underbrace{(B)}_{\text{Ziel}}$$

Es ist also direkt ersichtlich, dass eine Phase konstanter Geschwindigkeit entfällt. Die höchste Geschwindigkeit in dieser Bewegung v_x wird also aufgrund der gleich langen Beschleunigungs- und Abbremsphases genau zwischen A und B erreicht. Die Zeit t_x ist der Zeitpunkt, an dem die maximale Geschwindigkeit v_x erreicht wird.

Es gilt also:

$$d_x = \frac{d(A, B)}{2} \implies t_x = \frac{d(A, B)}{2 \cdot v_{\text{max}}} \implies v_x = a_{\text{max}} \cdot t_x \left(= \frac{d_x}{t_x} \right)$$

Die Berechnungen in dieser Form werden später auch in der Implementierung verwendet.




Abbildung 6: Bewegung der Spidercam in zwei Phasen. t_x ist der Zeitpunkt, an dem abgebremst wird und $2t_x$ ist der Zeitpunkt, an dem die Spidercam ihren Zielort erreicht hat.

Abbrechen der Bewegung

Instruktionen zur Bewegung der Spidercam können zu jedem Zeitpunkt stattfinden. Befindet sich die Spidercam jedoch bereits in Bewegung während eine neue Instruktion ankommt, so wird die aktuelle Bewegung abgebrochen, indem die Spidercam sofort anfängt zu bremsen⁴. Die neue Bewegung beginnt dann erst, wenn die Spidercam ihre Geschwindigkeit auf 0 gebracht hat. Kommt eine neue Instruktion an, obwohl bereits eine Instruktion auf Ausführung wartet, so wird die alte Instruktion überschrieben, da diese als veraltet angenommen wird.

Für die weitere Implementierung ist es hier wichtig zu klären, wie sich die Bremsdistanz d_{DEC} , die Bremszeit t_{DEC} und das neue Ziel B' bestimmen lassen.

Die Bremsdistanz $d_{\rm DEC}$ ist die Distanz, die die Spidercam zurücklegt, wenn sie von ihrer aktuellen Geschwindigkeit v auf 0 abgebremst wird. Die Bremsdistanz ist also gleich der Fläche unter der Geschwindigkeitskurve v(t). Die Fläche unter der Kurve v(t) ist die Distanz, die die Spidercam zurücklegt (siehe Abbildung ??).




Abbildung 7: Berechnung der Bremsdistanz d_{DEC}

⁴Wenn bereits gebremst wird, muss nicht neu abgebremst werden.

Da die Beschleunigung konstant ist, gilt:

$$v(t) = \begin{cases} v_{\max} & \text{für Abbruch in Phase konstanter Geschwindigkeit} \\ a_{\max} \cdot t & \text{für Abbruch in Beschleunigungsphase} \end{cases}$$

Damit lassen sich dann die Bremszeit $t_{\rm DEC}$ und die Bremsdistanz $d_{\rm DEC}$ berechnen:

$$t_{\rm DEC} = \frac{v(t)}{a_{\rm max}} \implies d_{\rm DEC} = \frac{v(t)^2}{2 \cdot a_{\rm max}}$$

Die neue Position B' ist der Punkt, an dem die Spidercam anhalten würde, wenn sie von ihrer aktuellen Position A für die Bremsdistanz $d_{\rm DEC}$ in Richtung B fahren würde. Dazu wird der Vektor (B-A) normiert und mit der Bremsdistanz $d_{\rm DEC}$ multipliziert:

$$B' = A + \frac{d_{\text{DEC}}}{d(A, B)} \cdot (B - A)$$

2 Verfahrensbeschreibung

Für den zu simulierenden Sachverhalt lohnt es sich, jede Bewegung der Kamera in Phasen zu unterteilen, um unübersichtliche Strukturen zu vermeiden. So bietet es sich an, eine *Phase* (Phase) als entweder eine *Beschleunigungs*- (ACCELERATION), *Konstantgeschwindigkeits*- (CONSTANT_VELOCITY) oder eine *Bremsphase* (DECELERATION) zu definieren.

Eine *Bewegung* (Movement) besteht dann aus entweder einer Beschleunigungs-, einer Konstantgeschwindigkeits- und einer Bremsphase oder nur aus einer Beschleunigungs- und einer Bremsphase.

Eine Instanz der Spidercam (Spidercam) enthält dann zusätzlich zu bekannten Konstanten eine Liste von Bewegungen (movements) und eine einelementige Warteschlange (queue).

2.1 Datenstrukturen

Es werden folgende Datenstrukturen verwendet:

2.2 Algorithmen

Die genutzten Algorithmen unterteilen sich in zwei Kategorien:

- Verarbeitung der Eingabedatei
- Erstellung der Ausgabedatei

10

Verarbeitung der Eingabedatei

Die Eingabe wird wie folgt verarbeitet:

- 1. ...
- 2. ...
- 3. ...

Erstellung der Ausgabedatei

Die Ausgabe wird wie folgt erstellt:

- 1. ...
- 2. ...
- 3. ...

Besonders nennenwert ist hier

3 Programmbeschreibung

3.1 Klassen und Schnittstellen

Wie bereits in der Verfahrensbeschreibung beschrieben, werden folgende Datenstrukturen benötigt:

- ...
- ...
- ...

Die konkrete Implementierung der Datenstrukturen erfolgt wie in Abbildung ?? zu sehen.

Besonders nennenswert ist dabei

3.2 Algorithmen

Mithilfe der Funktion ... wird die Eingabedatei verarbeitet und die Datenstrukturen gefüllt.

Die Ausgabedatei wird mit Hilfe der Funktion ... erstellt.

3.3 Aufrufhierarchie

Die Aufrufhierarchie ist beispielhaft in Abbildung ?? zu sehen.




Abbildung 8: Beispiel für eine Aufrufhierarchie

4 Testing

Strategie

Die Testfälle wurden nach der Methode \dots ausgewählt. Die Testfälle sind in Tabelle $\ref{thm:property}$ aufgelistet. $\ref{thm:property}$

| Testfall | Eingabe | Erwartete Ausgabe | Bemerkung |
|-------------|---------|-------------------|-----------|
| Normalfälle | | | |
| Grenzfälle | | | |
| Fehlerfälle | | | |

Abbildung 9: Beispiel für eine Tabelle mit Testfällen

Beobachtungen

Es wurden folgende Beobachtungen gemacht:

- ...
- ...
- . . .

⁵Die Testfälle sind im Anhang ?? zu finden.

4.1 Laufzeitanalyse

Die Laufzeitanalyse wurde mit ... durchgeführt. Jeder Testfall wurde ... mal ausgeführt und im Anschluss die Laufzeiten gemittelt.

Für die einzelnen Testfälle aus Tabelle ?? ergeben sich die Laufzeiten in Tabelle ??.

| Testfall | Median | Mittelwert | Standardabweichung |
|-------------|--------|------------|--------------------|
| Normalfälle | | | |
| Grenzfälle | | | |
| Fehlerfälle | | | |

Abbildung 10: Beispiel für eine Tabelle mit Laufzeiten




Abbildung 11: Beispiel für eine graphische Darstellung der Laufzeiten

Besonders auffällig ist ..., da der Algorithmus in $\mathcal{O}(n^m)$ läuft.

Für den praktischen Einsatz muss die Laufzeit nochmals verbessert werden. Siehe dazu Abschnitt ??.

5 Abweichungen

Im Laufe der Entwicklung des Programms sind einige Abweichungen vom ursprünglichen Konzept aufgetreten. Diese sind:

• ...

• ...

Besonders nennenswert ist dabei ..., da

6 Zusammenfassung und Ausblick

6.1 Zusammenfassung

In dieser Arbeit wurde ein Programm zur ... entwickelt. Dabei wurde

Die ... wurden

6.2 Ausblick

In Zukunft könnte man zur Optimierung

Anhang

A Grafiken




Abbildung 12: Klassendiagramm des Programms

B Benutzeranleitung

B.1 Installation

Voraussetzungen

Vorgehen

B.2 Benutzung

Eingabe

Ausgabe

Kommandozeilenparameter

Beispiele

Fehlermeldungen

C Entwicklerdokumentation

Die Entwicklerdokumentation ist im Ordner python/docs zu finden.

Zum Generieren der Dokumentation wird das Tool pdoc verwendet. Dieses Tool generiert aus den Python-Dateien automatisch eine Dokumentation in HTML-Format mithilfe der Docstrings. Die Dokumentation kann mit dem Befehl in ?? generiert werden.⁶

```
pdoc spidercam_simulator -o docs --docformat 'google'
```

Abbildung 13: Generieren der Dokumentation

D Hilfsmittel

Die genutzten Hilfsmittel sind in ?? aufgeführt.

⁶Vorausgesetzt, dass das Tool pdoc installiert ist und im Ordner python ausgeführt wird.

| Тур | Tool | Hinweise |
|----------------|--------------------|-------------|
| CPU | AMD Ryzen 5 3600 | 6x 3.60 GHz |
| RAM | 32 GB | DDR4-3200 |
| Betriebssystem | Ubuntu | 20.04.1 LTS |
| IDE | Visual Studio Code | 1.49.0 |
| Compiler | Python | 3.8.5 |
| Debugger | Visual Studio Code | 1.49.0 |
| Linter | pylint | 2.5.3 |
| Testframework | unittest | 3.8.5 |
| Dokumentation | pdoc | 0.9.2 |

Abbildung 14: Hilfsmittel

E Quellcode

Listing 1: Quellcode für /python/project_name/__init__.py

```
import argparse
   import configparser
   import logging
   import os
   import sys
   import spidercam_simulator
   def setup():
10
       """Sets up the logger and config"""
       # reading the config file
       cfg = configparser.ConfigParser()
14
       cfg.read("config.ini")
16
       # setting up the logger
       logging_dir = spidercam_simulator.find_location(cfg["io"]["logging_dir"])
18
19
       logging.basicConfig(
```

```
level=logging.INFO,
           format="%(asctime)s - %(name)s - %(levelname)s - %(message)s (%(filename)s:%(
       lineno)d)",
           datefmt="%Y/%m/%d %I:%M:%S %p",
           handlers=[
24
               logging.FileHandler(
                    filename=os.path.join(
                        os.path.dirname(os.path.dirname(os.path.abspath(__file__))),
                        "logs",
                        "spidercam_simulator.log",
                   ),
                   mode="w",
               ),
           ],
       )
       logging.info("Logging initialized")
36
       print(f"Logging to {os.path.join(logging_dir, 'spidercam_simulator.log')}")
       # Logging configuration
       for section in cfg.sections():
40
           for key, value in cfg[section].items():
41
               logging.debug("Config: %s.%s = %s", section, key, value)
42
       logging.debug("Config file read")
       # Setup: Setting up Arguments
46
       logging.info("Reading arguments")
       parser = argparse.ArgumentParser()
       parser.add_argument("--input", "-f", help="File or directory to parse")
50
       parser.add_argument(
           "--output", "-o", help="Output directory (needs to be different from input)"
       parser.add_argument("--debug", "-d", help="Debug mode", action="store_true")
       parser.add_argument(
           "--no-plot", "-np", help="Disable plotting", action="store_true"
       ags = parser.parse_args()
58
       if ags.debug:
           logging.getLogger().addHandler(logging.StreamHandler())
           logging.getLogger().setLevel(logging.DEBUG)
           logging.info("Debug mode enabled")
65
       logging.debug("Arguments read")
66
67
       # logging configuration
       for key, value in vars(ags).items():
69
           logging.debug("Argument: %s = %s", key, value)
70
```

```
# use defaults if no arguments are passed
        if ags.input is None:
            ags.input = cfg["io"]["input_dir"]
75
        ags.input = spidercam_simulator.find_location(ags.input)
76
        logging.debug("Input file/directory: %s", ags.input)
78
        if ags.output is None:
80
            ags.output = cfg["io"]["output_dir"]
81
82
        ags.output = spidercam_simulator.find_location(ags.output)
83
84
        logging.debug("Output directory: %s", ags.output)
85
        # check if files/directories exist
87
        if not os.path.exists(ags.input):
88
            logging.error("Input file/directory %s does not exist", ags.input)
89
            sys.exit(1)
91
        if not os.path.exists(ags.output):
92
            logging.error(
                "Output directory %s does not exist. Please create it first.", ags.output
95
96
            sys.exit(1)
97
        # check if input and output are the same
        if os.path.samefile(ags.input, ags.output):
99
            logging.error("Input and output directories are the same")
            sys.exit(1)
101
        logging.info("Setup complete")
        return cfg, ags
    config, args = setup()
   logging.info("Starting spidercam_simulator")
109
   input_queue = [args.input] if os.path.isfile(args.input) else os.listdir(args.input)
   logging.info("Found %s files/directories to process", len(input_queue))
113
114
   for file in input_queue:
        if file == ".gitkeep":
116
            continue
118
        logging.info("Processing %s", file)
120
        file_handler = spidercam_simulator.FileHandler(
```

```
os.path.join(args.input, file), args.output
        contents = file_handler.read_file()
124
        logging.debug("File contents: %s", contents)
126
        input_dict = spidercam_simulator.Parser.parse_input(contents)
        logging.debug("Input dictionary: %s", input_dict)
130
131
        controller = spidercam_simulator.Controller.from_dict(input_dict)
133
        logging.info("Running controller %s", repr(controller))
135
        cam_positions, rope_lengths = controller.run()
136
        logging.debug("Cam positions: %s", cam_positions)
138
139
        logging.debug("Rope lengths: %s", rope_lengths)
140
        output1, output2 = spidercam_simulator.Parser.parse_output(
            input_dict["dim"], input_dict["freq"], cam_positions, rope_lengths
        )
143
        file_handler.write_files(output1, output2)
145
146
        if not args.no_plot:
147
            plotter = spidercam_simulator.Plotter(
148
                input_dict["dim"],
                input_dict["freq"],
                cam\_positions,
                rope_lengths,
152
                args.output,
                os.path.splitext(file)[0],
            )
            plotter.plot()
        # cleanup
        del file_handler
160
        del contents
        del input_dict
        del controller
        del cam_positions
164
        del rope_lengths
        del output1
166
        del output2
        logging.info("Finished processing %s", file)
169
        # file_handler.write_file(parsed)
```

```
# Ending the program
logging.info("Ending spidercam_simulator")
```

Listing 2: Quellcode für /python/project_name/__main__.py

```
from __future__ import annotations
   import logging
   import numpy as np
   import spidercam_simulator
   class Controller:
9
               A class for initializing and controlling the spidercam"""
       def __init__(
           self,
           dim: tuple = (1, 1, 1),
           start: tuple = (0, 0, 0),
15
           max_velocity: float = 1.0,
           acceleration: float = 1.0,
           freq: float = 1.0,
18
           instructions: list[spidercam_simulator.Instruction] = None,
19
       ) -> None:
20
           0.0.0
                  Initializes the Controller class
           Args:
               dim (tuple, optional): The dimensions of the field. Defaults to (1, 1, 1).
               start (tuple, optional): The starting position of the spidercam. Defaults
       to (0, 0, 0).
               max_velocity (float, optional): The maximum velocity of the spidercam.
       Defaults to 1.0.
               acceleration (float, optional): The maximum acceleration of the spidercam.
        Defaults to 1.0.
               freq (float, optional): The discrete time frequency. Defaults to 1.0.
               instructions (list, optional): The instructions for the spidercam.
       Defaults to [].
30
           Returns:
               None
           self.logger = logging.getLogger(__name__)
           self.logger.debug(
                "Initializing Controller with dim=%s, start=%s, max_velocity=%s,
36
       acceleration=%s, freq=%s, instructions=%s",
               dim,
               start,
38
               max_velocity,
               acceleration,
40
               freq,
41
               instructions,
```

```
)
43
44
           self.dim = dim
           self.spidercam = spidercam_simulator.Spidercam(
46
               self, max_velocity, acceleration, start
47
48
           self.freq = freq
           self.instructions = instructions
50
51
           self.cam_positions = []
52
           self.rope_lengths = []
           self.store_anchors()
       def store_anchors(self) -> None:
                   Stores the anchor positions in regard to the dimensions
           Returns:
              None
           # Anchors are at the top corners of the field
64
           self.anchors = [
               (0, 0, self.dim[2]),
                (self.dim[0], 0, self.dim[2]),
               (0, self.dim[1], self.dim[2]),
               (self.dim[0], self.dim[1], self.dim[2]),
           1
       @classmethod
       def from_dict(cls, data: dict) -> "Controller":
                   Creates a Controller object from a dictionary
           Args:
               data (dict): The dictionary to create the Controller object from
                    - dim (tuple): The dimensions of the field
                    - start (tuple): The starting position of the spidercam
                   - max_velocity (float): The maximum velocity of the spidercam
80
                   - acceleration (float): The maximum acceleration of the spidercam
81
                    - freq (float): The discrete time frequency
82
                    - instructions (list): The instructions for the spidercam
85
           Returns:
               Controller: The Controller object
86
88
           cls.logger = logging.getLogger(__name__)
89
           cls.logger.debug("Creating Controller from dict %s", data)
90
           return cls(**data)
91
92
       def __repr__(self) -> str:
93
```

```
Returns a string representation of the Controller object
94
95
           Returns:
                str: The string representation of the Controller object
97
98
            return f"Controller({self.dim=}, {self.spidercam.start=}, {self.spidercam.
99
       max_velocity=}, {self.spidercam.acceleration=}, {self.freq=}, {self.instructions
       =})"
        def run(self) -> tuple[list[tuple], list[tuple]]:
101
                    Runs the instructions for the spidercam
            Returns:
               tuple[list[tuple], list[tuple]]: The positions and rope lengths for each
        time step
            current_time = 0
108
            while True:
                self.logger.info("Current time: %s", current_time)
                if len(self.instructions) != 0:
                    # Check if there is a new instruction
                    if current_time >= self.instructions[0].start_time:
                        instruction = self.instructions.pop(0)
                        self.spidercam.move(instruction)
                else:
119
                    self.spidercam.move()
                # Store cam_positions and rope_lengths
                position = self.spidercam.get_position(current_time)
                self.logger.info("Current position: %s", position)
                self.cam_positions.append(position)
                self.rope_lengths.append(self.get_rope_lengths(position))
                # Check if the last instruction is finished
129
                if (
                    len(self.instructions) == 0
                    and self.spidercam.movements[-1].end_time() < current_time</pre>
                    and self.spidercam.queue is None
                ):
                    self.logger.info(
                        "Last instruction finished and no more instructions left"
136
                    )
                    break
138
                current_time += 1 / self.freq
140
```

```
return self.cam_positions, self.rope_lengths
142
143
       def get_rope_lengths(self, position: tuple) -> list[tuple]:
144
                    Returns the rope lengths for a given position
146
            Returns:
147
              list[tuple]: The rope lengths
149
            rope_lengths = [
                np.linalg.norm(np.array(anchor) - np.array(position))
                for anchor in self.anchors
153
            1
            self.logger.debug("Rope lengths: %s", rope_lengths)
156
            return rope_lengths
```

Listing 3: Quellcode für /python/project_name/controller.py

```
import logging
   import os
   import numpy as np
   class FileHandler:
               A class for handling input and output"""
8
       def __init__(self, input_file: str, output_dir: str) -> None:
           """Initializes the FileHandler class
           Args:
13
               input_file (str): The path to the file to read
               output_dir (str): The path to the directory to write
16
           Returns:
               None
18
19
           self.logger = logging.getLogger(__name__)
           self.logger.debug(
               "Initializing FileHandler with input_file %s and output_dir %s",
               input_file,
               output_dir,
26
           )
           self.input_file = input_file
28
           self.output_dir = output_dir
           # removes file ending from input
30
           self.output_files = (
               os.path.join(
```

```
output_dir, os.path.basename(input_file).split(".")[0] + "_1.csv"
33
               ),
34
               os.path.join(
                    output_dir, os.path.basename(input_file).split(".")[0] + "_2.csv"
36
37
               ),
           )
38
       def read_file(self) -> str:
40
           """Reads the file
41
42
           Returns:
44
              str: The contents of the file
45
           self.logger.info("Reading file %s", self.input_file)
47
           with open(self.input_file, "r", encoding="utf-8") as file:
49
50
               return file.read()
       def write_files(self, output1: str, output2: str) -> None:
           """Writes the output to two files
54
           Args:
               output1 (str): The contents to write to the first file
               output2 (str): The contents to write to the second file
57
58
           Returns:
59
               None
62
           self.logger.info(
63
               "Writing output to files %s and %s",
               self.output_files[0],
               self.output_files[1],
66
           )
           with open(self.output_files[0], "w", encoding="utf-8") as file:
               file.write(output1)
           with open(self.output_files[1], "w", encoding="utf-8") as file:
               file.write(output2)
74
   def find_location(file: str) -> str:
              Finds the location of the given file/directory
       Looks in the following locations:
78
           - The current working directory
           - The directory of the script
80
           - The directory of the script's parent
81
           - The home directory
82
           - The root directory
83
```

```
84
       Args:
85
            file (str): The path to the given file/directory
86
87
       Returns:
88
            str: The absolute path to the given file/directory
89
90
91
       try:
92
            logger = logging.getLogger(__name__)
93
            logger.debug("Finding location of file/directory %s", file)
94
95
        except NameError:
            pass
96
97
        locations = [
98
            "", # check absolute
            os.getcwd(), # Current working directory
101
            os.path.dirname(os.path.realpath(__file__)), # Directory of the script
            os.path.dirname(
                os.path.dirname(os.path.realpath(__file__))
               # Directory of the script's parent
            os.path.expanduser("~"), # Home directory
105
            os.path.sep, # Root directory
        ]
        for location in locations:
            if os.path.exists(os.path.join(location, file)):
                return os.path.join(location, file)
        raise FileNotFoundError(f"Could not find file/directory {repr(file)}")
114
    class Parser:
116
                A class for parsing input strings"""
118
        logger = logging.getLogger(__name__)
120
        @staticmethod
        def parse_input(string: str) -> dict:
            """Parses the given string
            Example file contents:
126
            # Beispiel 2
            dim 70 100 30
            start 10 80 10
129
            vmax 6
            amax 2
            freq 2
            0 50 40 30
            20 10 80 10  # 2: Anweisung beginnt nach Ende der vorherigen
134
```

```
22 50 40 30
                        # 3: Die Bremsung der vorherigen Anweisung wird eingeleitet
135
                            # 4: Bremsung von Anweisung 2 noch nicht beendet -> Anweisung
            23 35 50 30
       3 wird ignoriert
            27.5 10 80 20
                            # 5: Anweisung 5 endete nicht zu den diskreten Zeitpunken ->
       offset beachten
            Args:
140
               string (str): The string to parse
141
142
            Returns:
143
               dict: The parsed string
                    - dim (tuple): The dimensions of the field
                    - start (tuple): The starting position of the spidercam
146
                    - max_velocity (float): The maximum velocity of the spidercam
                    - acceleration (float): The maximum acceleration of the spidercam
                    - freq (float): The discrete time frequency
                    - instructions (list): The instructions for the spidercam
            0.0.0
            Parser.logger.debug("Parsing string %s", string)
154
            lines = string.splitlines()
            instructions = []
            # Clean up the lines and remove comments
158
            for i, line in enumerate(lines):
                lines[i] = line.split("#")[0].strip()
            # Remove empty lines
            lines = list(filter(None, lines))
            # Parse the lines
            for i. line in enumerate(lines):
166
                if line.startswith("dim"):
                    dim = tuple(map(int, line.split()[1:]))
                elif line.startswith("start"):
                    start = tuple(map(int, line.split()[1:]))
                elif line.startswith("vmax"):
                    max_velocity = float(line.split()[1])
                elif line.startswith("amax"):
                    acceleration = float(line.split()[1])
                elif line.startswith("freq"):
                    freq = float(line.split()[1])
                else:
                    instructions.append(Instruction.parse(line))
178
            else:
                if not instructions:
180
                    raise ValueError("No instructions found")
181
            # Check if the dimensions are valid
183
```

```
if len(dim) != 3:
184
                raise ValueError("The dimensions are invalid")
            # Check if the starting position is valid
187
            if len(start) != 3 or not all(0 <= i <= j for i, j in zip(start, dim)):</pre>
188
                raise ValueError("The starting position is invalid")
189
            # Check if the maximum velocity is valid
191
            if max_velocity <= 0:</pre>
                raise ValueError("The maximum velocity is invalid")
            # Check if the maximum acceleration is valid
            if acceleration <= 0:</pre>
196
                raise ValueError("The maximum acceleration is invalid")
            # Check if the discrete time frequency is valid
            if freq <= 0:
                raise ValueError("The discrete time frequency is invalid")
            # Check if the instructions are valid
            for i, instruction in enumerate(instructions):
                if not all(0 <= j <= k for j, k in zip(instruction.destination, dim)):</pre>
205
                    raise ValueError(f"Instruction {i + 1} is invalid")
            return {
                "dim": dim,
                "start": start,
                "max_velocity": max_velocity,
                "acceleration": acceleration,
                "freq": freq,
                "instructions": instructions,
214
            }
        # returns two strings
        @staticmethod
        def parse_output(
            dim: tuple,
            freq: float,
            cam_positions: list[tuple],
            rope_lengths: list[tuple],
        ) -> tuple:
            """Parses the output
226
            Example file contents (first output: lengths of the ropes):
            83.06623, 82.9059, [...], 64.0056, 64.0312 # Rope 1
            101.9803, 101.9803, [...], 101.9803, 101.9803 # Rope 2
            101.9803, 101.9803, [...], 101.9803, 101.9803 # Rope 3
            101.9803, 101.9803, [...], 101.9803, 101.9803 # Rope 4
```

```
Example file contents (second output: dimensions, time stamps, positions of
        the camera):
            70, 100, 30 # Dimensions
            0.0, 0.5, 1.0, [...], 20.5, 21.0 # Time stamps
238
            10.0, 10.16, 10.66, [...], 20.0, 20.0 # x coordinates
            80.0, 80.0, 80.0, [...], 80.0, 80.0 # y coordinates
            10.0, 10.0, 10.0, [...], 10.0, 10.0 # z coordinates
242
243
            Args:
                dim (tuple): The dimensions of the field
246
                freq (float): The discrete time frequency
247
                cam_positions (list[tuple]): The positions of the camera
                rope_lengths (list[tuple]): The lengths of the ropes
            Returns:
               str: The parsed output
            Parser.logger.info(
255
                "Parsing output with #cam_positions=%d and #rope_lengths=%d",
                len(cam_positions),
                len(rope_lengths),
            )
            # Using numpy to transform the lists into numpy arrays for easier handling
            cam_positions = np.array(cam_positions)
            rope_lengths = np.array(rope_lengths)
            # transposing the arrays to get the correct shape
            cam_positions = cam_positions.T
            rope_lengths = rope_lengths.T
267
            # creating the time stamps
            time\_stamps = np.arange(0, len(cam\_positions[0]) / freq, 1 / freq)
            # creating the output strings
            output1 = "\n".join(",".join(map(str, rope)) for rope in rope_lengths)
            # adding the dimensions to the output
            output2 = f"{dim[0]},{dim[1]},{dim[2]}\n"
            # adding the time stamps to the output
            output2 += ",".join(map(str, time_stamps)) + "\n"
280
            # adding the positions of the camera to the output
281
            output2 += ",".join(map(str, cam_positions[0])) + "\n"
282
            output2 += ",".join(map(str, cam_positions[1])) + "\n"
            output2 += ",".join(map(str, cam_positions[2])) + "\n"
```

```
285
            # output2 = "\n".join(
286
                 ",".join(map(str, line)) for line in [dim, time_stamps, *cam_positions]
288
289
            Parser.logger.debug("Parsed output")
290
            return output1, output2
293
294
   class Instruction:
              A class for defining an instruction"""
296
297
        def __init__(self, start_time: float = 0.0, destination: tuple = (0, 0, 0)) ->
298
       None:
            """Initializes the Instruction class
300
301
                start_time (float, optional): The time to start the instruction. Defaults
302
        to 0.0.
                destination (tuple, optional): The destination of the instruction.
303
       Defaults to (0, 0, 0).
            Returns:
                None
            0.0.0
307
            self.logger = logging.getLogger(__name__)
            self.logger.debug(
                "Initializing Instruction with start_time=%f and destination=%s",
                start_time,
                destination,
312
            self.start_time = start_time
            self.destination = destination
       @classmethod
        def parse(cls, data: str) -> "Instruction":
            """Parses an instruction from a string
320
            Args:
                data (str): The string to parse the instruction from
                    - format: start_time x y z
324
            Returns:
                Instruction: The instruction
            cls.logger = logging.getLogger(__name__)
            cls.logger.debug("Parsing instruction from %s", data)
329
331
            try:
                start_time, x, y, z = data.split(" ")
```

```
except ValueError as exp:
                raise ValueError(
                    f"Invalid instruction format (expected: start_time x y z), got: {data}
                ) from exp
336
            return cls(float(start_time), (float(x), float(y), float(z)))
        def __repr__(self) -> str:
340
            """Returns the representation of the instruction
341
343
            Args:
                None
344
345
            Returns:
346
                str: The representation of the instruction
348
349
            return (
                f"Instruction(start_time={self.start_time}, destination={self.destination
       })"
```

Listing 4: Quellcode für /python/project_name/io.py

```
from __future__ import annotations
   import logging
   import numpy as np
   import spidercam_simulator
   class Movement:
                A class for defining a movement"""
       phases: list[spidercam_simulator.Phase] = []
       def __init__(
           self,
15
           spidercam: spidercam_simulator.Spidercam,
           start_time: float = 0,
           start: tuple = (0, 0, 0),
18
           destination: tuple = (0, 0, 0),
       ) -> None:
                  Initializes the Movement class
           Args:
               spidercam (Spidercam): The spidercam instance
24
               start_time (float, optional): The time to start the movement. Defaults to
               start (tuple, optional): The starting position. Defaults to (0, 0, 0).
```

```
destination (tuple, optional): The destination position. Defaults to (0,
           Returns:
28
               None
29
           0.00
30
           self.logger = logging.getLogger(__name__)
31
           self.logger.info(
               "Initializing Movement at %s with start %s and destination %s",
               start_time,
               start,
35
               destination,
37
38
           self.spidercam = spidercam
39
           self.start_time = start_time
40
           self.start = start
41
           self.destination = destination
42
43
           self.calculate_phases()
44
       def duration(self) -> float:
46
                 Returns the duration of the movement
47
48
           Returns:
49
               float: The duration of the movement
50
           return sum(phase.duration for phase in self.phases)
53
       def distance(self) -> float:
54
                  Returns the distance of the movement
55
56
           Returns:
              float: The distance of the movement
59
60
           return sum(phase.distance for phase in self.phases)
61
       def end_time(self) -> float:
           """ Returns the end time of the movement
63
64
           Returns:
              float: The end time of the movement
67
           return self.start_time + self.duration()
68
69
       def calculate_phases(self) -> None:
70
           """ Calculates the phases of the movement
           Returns:
             None
75
           # HERE 3
76
```

```
self.logger.info("Calculating phases")
77
            distance = np.linalg.norm(np.array(self.destination) - np.array(self.start))
80
            # Check how many phases are needed
81
            if distance <= 2 * self.spidercam.dist_vmax:</pre>
82
                # Only acceleration and deceleration
                self.logger.debug("Only acceleration and deceleration needed")
84
85
                # Calculate middle point
                middle_point = (
                    self.start + (np.array(self.destination) - np.array(self.start)) / 2
89
                self.phases = [
                    spidercam_simulator.Phase(
91
                        self,
                        spidercam_simulator.Phase.Mode.ACCELERATION,
93
                        self.start,
94
                        middle_point,
                        0.0,
                    ),
                    spidercam_simulator.Phase(
98
99
                        spidercam_simulator.Phase.Mode.DECELERATION,
                        middle_point,
                        self.destination,
                        # starting velocity is the velocity at the end of the acceleration
         phase
                        \# v = sqrt(ad)
                        np.sqrt(self.spidercam.acceleration * distance),
                    ),
106
                ]
            else:
                # Acceleration, constant velocity and deceleration
                self.logger.debug("Acceleration, constant velocity and deceleration needed
        ")
                # Calculate needed points
                point_a = (
                    np.array(self.start)
                    + (np.array(self.destination) - np.array(self.start))
                    * self.spidercam.dist_vmax
                    / distance
                point_b = (
                    np.array(self.destination)
                    - (np.array(self.destination) - np.array(self.start))
                    * self.spidercam.dist_vmax
```

```
/ distance
126
128
                self.phases = [
129
                    spidercam_simulator.Phase(
130
                         spidercam_simulator.Phase.Mode.ACCELERATION,
                         self.start,
                         point_a,
                         0.0,
135
                    ),
136
                    spidercam_simulator.Phase(
137
                         self,
                         spidercam_simulator.Phase.Mode.CONSTANT_VELOCITY,
139
                         point_a,
140
                         point_b,
                         self.spidercam.max_velocity,
142
143
                    ),
                    spidercam_simulator.Phase(
                         self,
                         spidercam_simulator.Phase.Mode.DECELERATION,
146
                         point_b,
147
                         self.destination,
148
                         self.spidercam.max_velocity,
                    ),
                ]
        def start_deceleration(self, time: float) -> None:
            0.00
                    Starts deceleration
            Args:
156
                time (float): The time to start deceleration
            Returns:
                None
            # HERE 2
            self.logger.info("Starting deceleration at %s", time)
164
            # Getting the phase that is active at the time
            # and the time offset of the phase
            # update all phases after the phase
            time_sum = self.start_time
            for phase in self.phases:
                # Skip phases before the time
                if time_sum + phase.duration < time:</pre>
                    time_sum += phase.duration
                    continue
```

```
# Nothing to do if already decelerating
               if phase.mode == spidercam_simulator.Phase.Mode.DECELERATION:
                    self.logger.debug("Already decelerating, nothing to do")
180
                    return
181
               offset = time - time_sum
               # Found phase should end at offset
185
               phase.destination = phase.get_position(offset)
186
               phase.update()
188
               # Update next phases
               # There always is a next phase because the final phase is deceleration and
        the previous phase was not
               next_phase = self.phases[self.phases.index(phase) + 1]
               next_phase.start = phase.destination
               next_phase.starting_velocity = (
                    self.spidercam.max_velocity
                    if phase.mode is spidercam_simulator.Phase.Mode.CONSTANT_VELOCITY
196
                    else self.spidercam.acceleration * offset
               next_phase.mode = spidercam_simulator.Phase.Mode.DECELERATION
               next_phase.destination = next_phase.get_position(
                    next_phase.starting_velocity / self.spidercam.acceleration
               next_phase.update()
               # If there is a phase after the next phase, pop it
               if len(self.phases) > self.phases.index(next_phase) + 1:
                    self.phases.pop(self.phases.index(next_phase) + 1)
               break
           # # If there are two deceleration phases at the end, delete the second one
           # if (
                 self.phases[-1].mode == spidercam_simulator.Phase.Mode.DECELERATION
           #
                 and self.phases[-2].mode == spidercam_simulator.Phase.Mode.DECELERATION
           #):
                 self.phases.pop()
           # Update the destination of the movement
218
            self.destination = self.phases[-1].destination
219
           # Debug: Check if destination of movement is the same as the destination of
       the last phase
            if not np.array_equal(self.destination, self.phases[-1].destination):
               self.logger.error(
                    "Destination of movement is not the same as the destination of the
       last phase (%s != %s)",
```

```
self.destination,
                    self.phases[-1].destination,
                )
       def get_phase(self, time: float) -> spidercam_simulator.Phase:
229
                    Returns the phase at the given time
230
            Args:
                time (float): The time to get the phase at
234
            Returns:
236
               Phase: The phase at the given time
            time_sum = self.start_time
            for phase in self.phases:
                if time_sum + phase.duration > time:
                    return phase
                time_sum += phase.duration
243
            return self.phases[-1]
246
        def __repr__(self):
247
            return f"Movement(start={repr(self.start)}, destination={repr(self.destination
248
        )}, start_time={self.start_time}, duration={self.duration()}, distance={self.
       distance()})"
249
       def get_position(self, time: float) -> tuple:
                    Returns the position of the movement at the time
            Args:
253
                time (float): The time to get the position for
            Returns:
256
               tuple: The position of the movement at the time
            self.logger.info("Getting position for time %s", time)
261
            # Getting the phase that is active at the time
262
            # and the time offset of the phase
            time_sum = self.start_time
265
            for phase in self.phases:
                if time_sum + phase.duration >= time:
                    return phase.get_position(time - time_sum)
                time_sum += phase.duration
            raise Exception("No phase found")
```

Listing 5: Quellcode für /python/project_name/movement.py

```
from __future__ import annotations
   import logging
   from enum import Enum
   import numpy as np
   import spidercam_simulator
   class Phase:
10
       0.0.0
               A class for defining a phase"""
       Mode = Enum("Mode", ["ACCELERATION", "CONSTANT_VELOCITY", "DECELERATION"])
14
       def __init__(
           self,
16
           movement: spidercam_simulator.Movement,
           mode: Mode,
18
           start: tuple = (0, 0, 0),
           destination: tuple = (0, 0, 0),
           starting_velocity: float = 0,
       ) -> None:
           0.0.0
                  Initializes the Phase class
           Args:
               movement (Movement): The movement instance
               mode (Mode): The type of phase. Can be ACCELERATION, CONSTANT_VELOCITY, or
        DECELERATION
               start (tuple, optional): The starting position. Defaults to (0, 0, 0).
28
               destination (tuple, optional): The destination position. Defaults to (0,
       0, 0).
               starting_velocity (float, optional): The starting velocity. Defaults to 0.
30
           Returns:
               None
           self.logger = logging.getLogger(__name__)
           self.logger.info(
36
               "Initializing Phase with mode %s, start %s, destination %s, and starting
37
       velocity %s",
               mode,
               start,
40
               destination,
               starting_velocity,
41
           )
43
           self.movement = movement
44
           self.mode = mode
45
           self.start = start
46
           self.destination = destination
47
           self.starting_velocity = starting_velocity
48
```

```
49
            self.update()
51
       def update(self) -> None:
                  Updates the phase
53
54
           Args:
               None
56
57
           Returns:
58
              None
60
           self.logger.debug("Updating phase %s", self.mode)
61
62
           self.distance = self.calc_distance()
63
           self.duration = self.calc_duration()
64
           self.logger.debug(
                "Updated phase with distance %s and duration %s",
67
                self.distance,
                self.duration,
           )
70
       def calc_distance(self) -> float:
                  Returns the distance of the phase
74
           Returns:
75
              float: The distance of the phase
           return np.linalg.norm(np.array(self.destination) - np.array(self.start))
79
       def calc_duration(self) -> float:
80
                 Returns the duration of the phase
82
83
           Returns:
              float: The duration of the phase
84
86
           if self.mode == Phase.Mode.ACCELERATION:
87
                # t = sqrt(2 * d / a)
88
                return np.sqrt((2 * self.distance) / self.movement.spidercam.acceleration)
           elif self.mode == Phase.Mode.CONSTANT_VELOCITY:
90
                #t=d/v
91
                return self.distance / self.starting_velocity
92
           elif self.mode == Phase.Mode.DECELERATION:
93
                \# t = v0 / a, because final velocity is 0
94
                return self.starting_velocity / self.movement.spidercam.acceleration
95
96
       def get_position(self, offset: float) -> tuple:
97
                   Returns the position of the phase after a given offset
98
99
```

```
100
            Args:
                offset (float): The offset to get the position after
            Returns:
               tuple: The position of the phase after the given offset
104
            self.logger.debug(
                "Getting position after %s seconds, mode %s", offset, self.mode
108
            # if offset > self.duration:
                self.logger.debug(
                      f"Offset {offset} is greater than duration {self.duration},
        returning destination {repr(self.destination)}"
            #
                  return self.destination
            if self.mode == Phase.Mode.ACCELERATION:
                distance = self.movement.spidercam.acceleration * offset**2 / 2
            elif self.mode == Phase.Mode.CONSTANT_VELOCITY:
                distance = self.starting_velocity * offset
120
            elif self.mode == Phase.Mode.DECELERATION:
                distance = (
                    self.starting_velocity * offset
                    - self.movement.spidercam.acceleration * offset**2 / 2
                )
            self.logger.debug("Phase distance: %s", distance)
            # if distance almost 0, return start
129
            if np.isclose(distance, 0):
                self.logger.debug(
                    "Distance is almost 0, returning start %s", repr(self.start)
                return self.start
            position = np.array(self.start) + (
                np.array(self.destination) - np.array(self.start)
137
            ) * distance / np.linalg.norm(np.array(self.destination) - np.array(self.start
        ))
            self.logger.debug("Phase position: %s", position)
140
            return tuple(position)
142
```

Listing 6: Quellcode für /python/project_name/phase.py

```
from __future__ import annotations
import logging
import matplotlib.pyplot as plt
import numpy as np
```

```
class Plotter:
               A class for plotting camera positions and rope lengths"""
8
9
       def __init__(
           self,
           dim: tuple = None,
           freq: float = 1.0,
           cam_positions: list = None,
14
           rope_lengths: list = None,
           output_dir: str = None,
16
           name: str = None,
       ) -> None:
18
           0.00
                  Initializes the Plotter class
           Args:
               dim (tuple, optional): The dimensions of the field. Defaults to None.
               freq (float, optional): The discrete time frequency. Defaults to 1.0.
               cam_positions (list, optional): The camera positions. Defaults to None.
               rope_lengths (list, optional): The rope lengths. Defaults to None.
               output_dir (str, optional): The output directory. Defaults to None.
26
               name (str, optional): The name of the plot. Defaults to None.
           Returns:
29
               None
30
           self.logger = logging.getLogger(__name__)
           # Setting log level info to suppress matplotlib font manager warnings
           self.logger.setLevel(logging.INFO)
35
36
           self.logger.info("Initializing Plotter for %s", name)
38
           self.dim = dim
39
           self.freq = freq
40
           self.cam_positions = np.array(cam_positions)
           self.rope_lengths = np.array(rope_lengths)
42
           self.output_dir = output_dir
43
           self.name = name
44
       def plot_cam_positions(self) -> None:
46
                   Plots the camera positions
47
48
           Returns:
              None
50
           0.0.0
51
           self.logger.info("Plotting camera positions for %s", self.name)
54
           # If output directory is not specified, plot to screen
```

```
if self.output_dir is None:
56
                plt.ion()
            # Plot camera positions projection = 3d
59
            fig = plt.figure()
60
            ax = fig.add_subplot(111, projection="3d")
            # Set axis labels
            ax.set_xlabel("X")
            ax.set_ylabel("Y")
65
            ax.set_zlabel("Z")
            # Set axis limits
            ax.set_xlim3d(0, self.dim[0])
            ax.set_ylim3d(0, self.dim[1])
            ax.set_zlim3d(0, self.dim[2])
            # Rotate so that origin is in the bottom left and z is up, angle is normal
            # ax.view_init(azim=0, elev=90)
            # Plot camera positions
            xline = self.cam_positions[:, 0]
77
            yline = self.cam_positions[:, 1]
            zline = self.cam_positions[:, 2]
80
            # Define color as distance from one point to the previous
81
            color = np.zeros(len(xline))
82
            for i in range(1, len(xline)):
                color[i] = np.linalg.norm(
                    np.array([xline[i], yline[i], zline[i]])
85
                    - np.array([xline[i - 1], yline[i - 1], zline[i - 1]])
                )
            # Plot camera positions
89
            ax.scatter(xline, yline, zline, c=color, cmap="coolwarm")
90
            # Plot start as big green x
            ax.scatter(xline[0], yline[0], zline[0], c="green", s=200, marker="x")
94
            # Set title for whole figure
95
            # fig.suptitle("Camera Positions for " + self.name)
            # Save or show plot
98
            if self.output_dir is None:
                plt.show()
            else:
                # Save at output + name + cam_pos.png
                plt.savefig(
                    f"{self.output_dir}/{self.name}_cam_pos.png",
                    bbox_inches="tight",
                    dpi=300,
106
```

```
109
       def plot_rope_lengths(self) -> None:
                    Plots the rope lengths
            Returns:
                None
115
            self.logger.info("Plotting rope lengths for %s", self.name)
116
            # If output directory is not specified, plot to screen
118
            if self.output_dir is None:
119
                plt.ion()
120
            # Plot rope lengths as a function of time (discrete)
            fig = plt.figure()
124
            # Set axis labels
            plt.xlabel("Time (s)")
            plt.ylabel("Rope Length (m)")
128
            # Set axis limits
            plt.xlim(0, len(self.rope_lengths) / self.freq)
            plt.ylim(0, np.max(self.rope_lengths) * 1.1)
            # Plot rope lengths
            plt.plot(
                np.arange(0, len(self.rope_lengths) / self.freq, 1 / self.freq),
                self.rope_lengths,
136
            )
137
            # Legend of Rope i
            plt.legend([f"Rope {i}" for i in range(len(self.rope_lengths[0]))])
140
            # Set title for whole figure
            # fig.suptitle("Rope Lengths for " + self.name)
            # Save or show plot
145
            if self.output_dir is None:
146
                plt.show()
            else:
                # Save at output + name + rope_lengths.png
149
                plt.savefig(
                    f"{self.output_dir}/{self.name}_rope_lengths.png",
                    bbox_inches="tight",
                    dpi=300,
                )
154
        def plot(self) -> None:
156
                    Plots the camera positions and rope lengths
```

```
Returns:
None
Self.logger.info("Plotting camera positions and rope lengths for %s", self.
name)

self.plot_cam_positions()
self.plot_rope_lengths()
```

Listing 7: Quellcode für /python/project_name/plotter.py

```
from __future__ import annotations
   import logging
   import spidercam_simulator
   class Spidercam:
                  A class for controlling the spidercam"""
       movements: list[spidercam_simulator.Movement] = []
       queue: spidercam_simulator.Movement = None
       def __init__(
14
           self,
           controller: spidercam_simulator.Controller,
           max_velocity: float = 1.0,
           acceleration: float = 1.0,
18
           start: tuple = (0, 0, 0),
       ) -> None:
20
           0.0.0
                  Initializes the Spidercam class
               controller (Controller): The controller instance
               max_velocity (float, optional): The maximum velocity of the spidercam.
       Defaults to 1.0.
               acceleration (float, optional): The maximum acceleration of the spidercam.
        Defaults to 1.0.
             start (tuple, optional): The starting position of the spidercam. Defaults
       to (0, 0, 0).
           Returns:
30
              None
           self.logger = logging.getLogger(__name__)
           self.logger.debug(
34
               "Initializing Spidercam with max_velocity=%s, acceleration=%s, start=%s",
               max_velocity,
```

```
acceleration,
37
               start,
           )
39
40
           self.controller = controller
41
           self.max_velocity = max_velocity
42
           self.acceleration = acceleration
           self.start = start
45
           self.movements = []
46
           self.queue = None
48
           self.calc_constants()
49
50
       def calc_constants(self) -> None:
                   Calculates the constants for the spidercam
54
           - time_vmax: The time it takes to reach the maximum velocity
           $t_{v_{max}} = \frac{v_{max}}{a_{max}}
           - dist_vmax: The distance it takes to reach the maximum velocity
           d_{v_{max}} = \frac{v_{max}^2}{2a_{max}}
58
59
           Returns:
               None
           0.00
           self.logger.debug("Calculating constraints for spidercam")
           self.time_vmax = self.max_velocity / self.acceleration
66
           self.dist_vmax = self.acceleration * self.time_vmax**2 / 2
67
       def move(
69
           self, instruction: spidercam_simulator.Instruction = None, time: float = -1.0
       ) -> None:
                      Moves the spidercam to a given position or updates the current
       movement at a given time
           Args:
74
               Instruction (Instruction): The instruction to move the spidercam. Defaults
        to None.
               time (float): The time to update the current movement at. Defaults to
       -1.0.
           Returns:
              None
79
           0.0.0
80
81
           # Check if parameters are valid
82
           if instruction is None and time == -1.0:
83
               self.logger.debug("No instruction or time given, returning")
84
```

```
return
85
86
            # No instruction given, update the current movement
            if instruction is None and time != -1.0:
88
                self.logger.debug("Updating movement at time %s", time)
89
90
                # If there is no movement in the queue, return
                if self.queue is None:
                    self.logger.debug("No movement in queue, returning")
93
                    return
                # If the last movement is finished, add the movement in the queue to the
96
       movements list
                if self.movements[-1].end_time() <= time:</pre>
97
                    self.logger.debug(
98
                        "Last movement is finished, adding queue to movements list"
                    self.movements.append(self.queue)
                    self.queue = None
                    return
                return
105
            # Instruction given, apply the instruction
            self.logger.debug("Moving spidercam with instruction %s", instruction)
            # First movement is always possible
            if len(self.movements) == 0:
                self.logger.debug("First movement registered")
                self.movements.append(
114
                    spidercam_simulator.Movement(
                        self, instruction.start_time, self.start, instruction.destination
                )
                return
            self.logger.debug("Checking if last movement is finished")
            self.logger.debug("Last movement: %s", self.movements[-1])
            # HFRF 1
            # If the last movement is not finished, decelerate and update the queue
            if self.movements[-1].end_time() > instruction.start_time:
                self.logger.debug("Last movement is not yet finished")
                self.logger.debug("Queueing instruction %s", instruction)
                # Decelerate
                self.movements[-1].start_deceleration(instruction.start_time)
                # Overwrite queue
```

```
self.queue = spidercam_simulator.Movement(
135
                    self,
136
                    self.movements[-1].end_time(),
                    self.movements[-1].destination,
138
                    instruction.destination,
139
                )
140
141
                return
            # REDUNDANT ?
144
            # If the last movement is finished and there is a queue, move to the queue
            if self.queue is not None:
146
                self.logger.debug("Last movement is finished and there is a queue")
147
                self.logger.debug("Executing queue")
148
                self.movements.append(self.queue)
                self.queue = None
                # Move to the destination after the gueue
                self.move(instruction)
                return
156
            # If the last movement is finished and there is no queue, move to the
       destination
            self.logger.debug("Last movement is finished and there is no queue")
158
            self.movements.append(
                spidercam_simulator.Movement(
                    max(self.movements[-1].end_time(), instruction.start_time),
                    self.movements[-1].destination,
164
                    instruction.destination,
            )
167
        def get_position(self, time: float) -> tuple:
                    Gets the position of the spidercam at a given time
            Args:
                time (float): The time to get the position at
            Returns:
                tuple: The position of the spidercam at the given time
176
            self.logger.debug("Getting position at time %s", time)
179
180
            self.move(time=time)
181
182
            # If there are no movements, return the start position
            if len(self.movements) == 0:
184
```

```
self.logger.debug("No movements registered, returning start position")
185
                return self.start
186
            # If the time is before the first movement, return the start position
188
            if time < self.movements[0].start_time:</pre>
189
                self.logger.debug("Time is before first movement, returning start position
190
        ")
                return self.start
            # If the time is after the last movement, return the destination of the last
       movement
            if time > self.movements[-1].end_time():
                self.logger.debug(
                    "Time is after last movement, returning destination of last movement"
196
                )
                return self.movements[-1].destination
            # If the time is during a movement, return the position of that movement
            for movement in self.movements:
                if movement.start_time <= time <= movement.end_time():</pre>
                    self.logger.debug(
                        "Time is during movement %s, returning position of movement",
204
                        movement,
                    )
                    return movement.get_position(time)
            # If the time is between movements, return the destination of the previous
       movement
            for i in range(len(self.movements) - 1):
                if self.movements[i].end_time() < time < self.movements[i + 1].start_time:</pre>
                    self.logger.debug(
                        "Time is between movements %s and %s, returning destination of
       previous movement",
                        self.movements[i],
                        self.movements[i + 1],
                    return self.movements[i].destination
            # If the time is not in any of the above cases, return the start position
219
            self.logger.debug(
                "Time is not in any of the above cases, returning start position"
```

Listing 8: Quellcode für /python/project_name/spidercam.py